

The Caddie

Instructions

Table of Contents

What’s In the Box?	1
Tech Specs	1
Features	2
How to Use Your Caddie	3
• Home Screen	3
• Viewer Screen	4
• Setting Up a Game	5
• Keeping Score	9
Troubleshooting	10
Warranty Info	10
Safety Info	11
Legal Notice	11
Compliance	12
Contact Us	13



Scan for
Online Manual

Features

45,000+ Courses

Get dialed in all around the world.

Built-In Magnet

Strongest magnets on the market.
Have no fear of it falling off.

Weather-Proof

Play with confidence rain or shine.

360° Hole View

See the entire hole before you take a swing.

FBC Distances

Front, Back and Center distances
from anywhere on the course.

Dynamic Hazard Distances

Exact distances to hazards so you can avoid them.

54 Hole Battery Life

Be dialed in for 3+ rounds.

Multiple Game Types

Play games against your friends.

Extremely Portable

Pack The Caddie in your golf bag
and bring it anywhere.


Advanced Analytics

Track your analytics and scores during the round.

How to Use Your Caddie

Home Screen

- **Auto-Detects Your Course:** No need to search, Caddie picks up your location and loads the course automatically.
- **Quick Access to Favorites:** The courses you selected during setup are ready to go.
- **Nearby Courses:** If you're not at a saved course, Caddie pulls a list of options based on your location.



Viewer Screen



In-Game Menu (Top Left): Quick access to settings and round details.



3D | 2D Icons: Switch camera views for a different perspective on the hole.



Greens Icon: This is for Greens View where you will only see the green in the viewer.



Drone Icon: Get a hole flyover for a bird's-eye view of what's ahead.



Setting Up a Game

1. **Select Your Round Details:** Choose between 9 or 18 holes based on your preferred game length. Pick your tee box (Gold, Blue, White, or Red) to match your playing style. Select your starting hole—begin at Hole 1 or jump in at Hole 10.

9:41 Sat Jun 11

Signal strength, Wi-Fi, 100% battery

76°F

Fairways & Blue Water

Los Angeles, California • 18 Holes • Par 72

View Scorecard

Select Holes

9 Holes

18 Holes

Select Tee

Gold
7,346 Yds

Blue
6,946 Yds

White
6,346 Yds

Red
5,846 Yds

Select Your Starting Hole

Hole 1

Hole 10


Who's Playing

You
HCP 9

Add Golfers

Start Round

Viewer Screen (cont.)



Tap for Distance:
Tap anywhere on the course to get the distance to that point and the remaining distance to the green.

Tee Distance:
Shows how far you've driven from the tee—track your power off the box.



Setting Up a Game (cont.)

3. **Choose Game Type & Scoring:** Pick between Stroke Play (lowest score wins) or Match Play (head-to-head). Choose Straight Up (gross scores) or enable Handicap scoring for an even playing field. If using handicaps, enter each player's handicap index to activate the auto-dot feature.

Game Type



Stroke Play

Lowest Score Wins



Match Play

Head-to-head

Scoring



Straight Up

Gross Scores



Handicap

Net Scores

Enter Handicap

Alec

 Gold (7,346 Yds)

HCP 19

John

 Gold (7,346 Yds)


HCP 9

Back

Finalize Game

Setting Up a Game (cont.)

4. **Review & Start Your Round:** The Round Overview lets you double-check all settings before you begin. If everything looks good, tap Start Round and hit the course! With the Pinned Caddie, setting up your game is quick and seamless—so you can focus on playing your best.



Keeping Score

- **Super Easy Score Slider:** Adjust your score with a simple swipe. No complicated inputs—just slide and confirm.
- **Running Score Total:** See your current score and score over par update in real time.
- **Auto-Dot Feature:** The red dots show who is “stroking” on this hole, automatically factoring in handicaps.

Granite Links Golf Course

Front 9

Hole 9 PAR 4 HCP 5

TEE 304 Yards

B Buck

Round Score 41 +5

1

2

3

4

5

6

7

A Alec

Round Score 39 +3

1

2

3

4

5

6

7

J John

Round Score 40 +4

1

2

3

4

5

6

7

P Parker

Round Score 34 -2

1

2

3

4

5

6

7

Scorecard

Next Hole →

Troubleshooting

The Caddie does not turn on?

Please recharge your Caddie.

The Caddie turns on but the app is not loading?

Please turn off your Caddie to let it reset, then turn back on.

The screen is black?

Please be sure your Caddie is turned on.

Why does my Caddie not charge?

Please make sure you are using the charger that came with your unit. Other chargers will not always work on this device.

How do I change from Yards to Meters?

Please see the in-game settings or your profile to pick your desired unit of measurement.

For other troubleshooting tips, please scan the QR code to access our online manual.

One Year Warranty

Your Pinned Golf Caddie is warrantied to be free of defects in materials and workmanship for one year after the date of purchase.

In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product using our prepaid postage.

This warranty does not cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than Pinned Golf. Please note, this warranty is not transferable.

Safety Warning

- Do not disassemble, repair or modify this product by unauthorized personnel.
- Please read the user manual before using this product and follow the instructions for correct operation. Improper use may cause damage.
- This product contains batteries, please do not use it in a flammable environment.
- Do not expose this product to excessive heat or cold, as this may cause battery damage, leakage, or explosion.
- Please ensure that the power adapter for this product matches the electrical outlet and use the manufacturer's recommended charging cable.
- Do not use this product near flammable materials to avoid fire hazards.
- This product uses a Lithium-based battery. Lithium batteries can overheat and cause damage if physically abused.
- If this product appears abnormal, such as overheating, emitting strange smells, smoking, etc., please stop using it immediately and contact us.

Legal Notice

By using this product, you agree that Pinned Golf LLC, will not be held legally responsible for any injury or damage to you, or any person or property caused by the user's improper operation and/or poor judgment while using this product.

Note: See Limited Warranty for other limitations to our liability.

FCC Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs/récepteurs exemptés de licence, conformes aux CNR d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne doit pas causer d'interférences.
2. Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable.

Avertissement radio pour les appareils mobiles:

L'équipement est conforme aux limites d'exposition aux rayonnements définies par IC pour les environnements non contrôlés. Une distance minimale de 20 cm doit être maintenue entre le radiateur et votre corps lors de l'installation et de l'utilisation de l'appareil.

IC ID: 33750-Caddie

Need Help?

Questions or concerns about your Caddie?

Reach out to us at
support@pinnedgolf.com

Video Tutorials

Your step-by-step video guide
to all things Caddie.



Leave Us a Review

Your feedback helps
improve our game.



Follow Us!

Monthly giveaways, free product,
huge discounts and more!



11:36

100

<

pinnedgolf

661 posts

28.3K followers

2,535 following

Sports & recreation
Better Vibes. Better Golf. 🏌️🎯🎵
Golf tech trusted by 150,000+ golfers
SHOP THE CADDIE! ⬇️👤
linktr.ee/pinnedgolf

@pinnedgolf

Following ▾

Message

Shop

▾

THE PINNED TEAM

DREAM GOLF TRIP DESTINATIONS

5 Reasons The Caddie Will Improve Your Game

